

[EN] User manual for battery chargers

Model: DCB118 / Lithium-Ion 4.5A charger

Please read these instructions carefully before using the device!

SAFETY RULES FOR THE CHARGER

SUITABLE FOR 12V TO 20V LI-ION BATTERIES

1. Protect the battery charger from rain and moisture. Water ingress into the charger increases the risk of electric shock.
2. Do not charge any other batteries. The charger is only suitable for charging compatible lithium-ion batteries within the specified voltage range; otherwise, there is a risk of fire or explosion.
3. Keep the battery charger clean. Dirt and debris can increase the risk of electric shock.
4. Check the charger, cable and plug before each use. Do not use the charger if any defects are found; never open it yourself.
5. Instead, have the device opened and repaired only by qualified personnel using original spare parts. Damaged chargers, cables and plugs increase the risk of electric shock.
6. Do not operate the charger on highly flammable surfaces (e.g. paper, textiles, etc.) or in flammable environments. The charger may become hot during charging, which could cause a fire.
7. Only connect the charger to a power source within the voltage range specified on the device.
8. Unplug the charger from the mains socket before carrying out any maintenance or cleaning to reduce the risk of electric shock.
9. Disconnect the charger from the mains when not in use. This reduces the risk of electric shock or damage to the charger should metallic objects fall into the openings.
10. Risk of electric shock! Do not touch the uninsulated part of the output connector or the uninsulated battery terminals.
11. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been instructed in the use of the appliance and supervised by a person responsible for their safety.
12. Children must be supervised to ensure they do not play with the device.
13. If the mains cable is damaged, do not replace it yourself; instead, return the device to our service organisation or contact qualified personnel.
14. Do not charge a defective battery.

OPERATION / BATTERY CHARGING

Charge the battery indoors only. Use only the battery chargers listed on the accessories page. Only these chargers are compatible with the lithium-ion battery in your power tool. The battery is supplied partially charged. To ensure the battery reaches its full capacity, charge it fully in the charger before using the power tool for the first time. The lithium-ion battery can be charged at any time without affecting its service life. Interrupting the charging process will not damage the battery. To remove the battery, press the battery release button and pull the battery downwards to remove it. Do not use excessive force. The battery is equipped with NTC temperature control, which only allows charging within a temperature range of 5 °C to 40 °C. This ensures a long battery life. Please observe the disposal instructions.

Unilux Item No. DE56-1105-EU / Plug type C "Euro plug"

Unilux Item No. DE56-1105-UK / Plug type G "Commonwealth plug"